

Logitech®

Harmony® 1100

Powerful control through a customisable touch screen

- One-touch, activity-based controls
- 3.5-inch (9-cm), full-colour touch screen
- Support for 5,000+ brands and 225,000+ devices
- RF wireless capability
- Customisable on-screen commands and icons



The Logitech® Harmony® 1100 gives you powerful home-entertainment control through a customisable, 3.5-inch (9-cm), full-colour touch screen. Controls are easy to access and backlit so you can find them in the dark. One-touch, activity-based controls turn on the right devices in the right order with a single command. It supports 5000+ brands and 225,000+ devices. RF wireless capability lets you control devices without direct line-of-sight, so you can keep components in a closed cabinet or even another room (requires Logitech® Harmony RF Extender, sold separately). And the on-screen commands are customisable, so you get the commands you want, when you want them.

SYSTEM REQUIREMENTS

Windows-based PC

- Windows® 2000, Windows® XP, Windows Vista®
- USB port
- CD-ROM drive
- Internet access

Mac OS-based PC

- Mac OS® X 10.3-10.5
- USB port
- CD-ROM drive
- Internet access



Logitech®
Harmony® 1100

PACKAGE SPECIFICATIONS

	Primary Pack	Master Shipper Carton
Part #	915-000076	n/a
Bar code	5099206011281 (EAN-13)	50992060112814 (SCC-14)
Weight	1330 g	5830 kg
Length	18.7 cm	37.2 cm
Width	8.4 cm	20 cm
Height/depth	27.6 cm	29.2 cm
Volume	4.335 dm ³	0.02172 m ³
1 primary pack	1	n/a
1 intermediate pack	0	n/a
1 master shipper carton	4	1
1 pallet EURO	336	84
1 container 20 ft	5760	1440
1 container 40 ft	11904	2976

PACKAGE CONTENT

- Harmony® 1100 remote control
- Charging station
- USB cable
- AC adapter
- Lithium-ion battery
- Installation CD
- Quick-start and features guides
- 2-year guarantee and full product support

